



YAMAHA

PARTS LIST

MODEL RD125B

YAMAHA MOTOR CO., LTD.

COPY RIGHT: ALL RIGHTS RESERVED

NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT PERMISSION.

YAMAHA

PARTS LIST

MODEL RD125B




FOREWORD

This Parts List related to the parts in use for the YAMAHA RD125B. When you ordering replacement parts for the RD125B, refer to this Parts List and write both part numbers and part names correctly.

1. Structure of Part No.

Yamaha parts are divided largely into two categories; general parts and standard parts, and each part No. has the following structure:



Note: Every standard No. begins with 9.



2. How to Use this Parts List

- (1) Except for steel balls (whose size is indicated in inches), the size of all parts is indicated in millimeters in the following manner.

Pipe (rubber or vinyl) Inside diameter - length
 O-ring Section area - inside diameter
 Washer, shim, collar Inside diameter - outside diameter - thickness (length)

- (2) Parts, which are to be supplied in the form of assemblies, are listed with an indentation of one letter's space, and a dot (.) is put

against the name of each part. If any two different assemblies (e.g., right and left side components) consist of almost the same type components, these two assemblies are listed in two lines, and then the names of component parts are listed in the subsequent lines with an indention as mentioned earlier. The quantity of parts is given in the following manner; that is, in the case of parts being the same in type between the right and left, a total quantity of parts is given. On the other hand, if the right and left side parts are different in type, the quantity of part(s) on each side is given.

Example

Description	Q'ty
CARBURETOR ASS'Y, left	1
CARBURETOR ASS'Y, right	1
. JET, pilot	2
. NOZZLE, main	2
.	
.	
.	
. LEVER, starter, left	1
. LEVER, starter, right	1

(3) Key to Symbols

U. R.	Use size (thickness) and/or number as required
U. N.	Use as many as you need
T	Number of teeth in a gear
V	Voltage for light bulbs
S	"S" type oil seal or "S" type circlip
SD	"SD" type oil seal
SO	"SO" type oil seal
SW	"SW" type oil seal
E	"E" type circlip
R	"R" type circlip
F/No.	Frame No. (Applicable machine No.)




FOREWORD

This Parts List related to the parts in use for the YAMAHA RD125B.
When you ordering replacement parts for the RD125B, refer to this Parts List and write both part numbers and part names correctly.

1. Structure of Part No.

Yamaha parts are divided largely into two categories; general parts and standard parts, and each part No. has the following structure:



Note: Every standard No. begins with 9.



2. How to Use this Parts List

- (1) Except for steel balls (whose size is indicated in inches), the size of all parts is indicated in millimeters in the following manner.

Pipe (rubber or vinyl) Inside diameter - length
O-ring Section area - inside diameter
Washer, shim, collar Inside diameter - outside diameter - thickness (length)

- (2) Parts, which are to be supplied in the form of assemblies, are listed with an indentation of one letter's space, and a dot (.) is put

against the name of each part. If any two different assemblies (e.g., right and left side components) consist of almost the same type components, these two assemblies are listed in two lines, and then the names of component parts are listed in the subsequent lines with an indentation as mentioned earlier. The quantity of parts is given in the following manner; that is, in the case of parts being the same in type between the right and left, a total quantity of parts is given. On the other hand, if the right and left side parts are different in type, the quantity of part(s) on each side is given.

Example

Description	Q'ty
CARBURETOR ASS'Y, left	1
CARBURETOR ASS'Y, right	1
. JET, pilot	2
. NOZZLE, main	2
.	
.	
.	
. LEVER, starter, left	1
. LEVER, starter, right	1

(3) Key to Symbols

U.R.	Use size (thickness) and/or number as required
U.N.	Use as many as you need
T	Number of teeth in a gear
V	Voltage for light bulbs
S	"S" type oil seal or "S" type circlip
SD	"SD" type oil seal
SO	"SO" type oil seal
SW	"SW" type oil seal
E	"E" type circlip
R	"R" type circlip
F/No.	Frame No. (Applicable machine No.)



- (4) The right and left in relation to parts are determined on the basis of the rider facing toward the front.
- (5) This Parts List is based on the model in the production line on Nov. 25, 1974. Accordingly, if any modifications which have been made to parts will be announced in the Yamaha Parts News. It is advisable that according to the Yamaha Parts News, You will make necessary corrections to the Parts List on hand to keep it up-to dated.



Fig. 28	Head Lamp	73
Fig. 29	Speedometer - Tachometer	75
Fig. 30	Tail Lamp	77
Fig. 31	Flasher Lamp	81
Fig. 32	Electrical	83

NUMERICAL INDEX

CONTENTS

ENGINE

Fig. 1	Crankcase · Cylinder	1
Fig. 2	Crankcase Cover	3
Fig. 3	Crank · Piston	5
Fig. 4	Clutch	9
Fig. 5	Transmission	11
Fig. 6	Shifter 1	15
Fig. 7	Shifter 2	17
Fig. 8	Kick Starter	19
Fig. 9	Tachometer Gear	21
Fig. 10	Intake	23
Fig. 11	Carburetor	25
Fig. 12	Exhaust	29
Fig. 13	Oil Pump	31
Fig. 14	A. C. Generator	35

CHASSIS


Fig. 15	Frame	39
Fig. 16	Side Cover · Box	41
Fig. 17	Rear Arm · Rear Cushion · Chain Case	43
Fig. 18	Stand · Footrest · Brake Pedal	45
Fig. 19	Front Fender · Rear Fender	47
Fig. 20	Front Fork	49
Fig. 21	Steering	53
Fig. 22	Handle · Wire	55
Fig. 23	Fuel Tank	59
Fig. 24	Oil Tank	61
Fig. 25	Seat	63
Fig. 26	Front Wheel	65
Fig. 27	Rear Wheel	69

ESTRUTURA - CHASSIS

ENGINE




Fig. 1 CRANKCASE · CYLINDER



CRANKCASE · CYLINDER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
1- 1	389-15111-00	CASE, crank left	1		
1- 2	389-15121-00	CASE, crank right	1		
1- 3	91810-05016	PIN, dowel (9.8-12-16)	2		
1- 4	389-15128-00	HOLDER	1		
1- 5	389-15118-00	HOLDER	1		
1- 6	92501-06012	SCREW, panhead	2		
1- 7	92501-06055	SCREW, panhead	2		
1- 8	92501-06060	SCREW, panhead	6		
1- 9	92501-06080	SCREW, panhead	1		
1-10	92501-06095	SCREW, panhead	1		
1-11	92501-06105	SCREW, panhead	1		
1-12	91810-02015	PIN, dowel (6.5-10-15)	2		
1-13	93603-14026	PIN, dowel (3-14)	1		
1-14	90340-12005	PLUG, drain (132-15351-00) ..	1		
1-15	90430-12038	GASKET (132-15353-00)	1		
1-16	90116-06100	BOLT (122-11361-00)	8		
1-17	396-11351-00	GASKET, cylinder	2		
1-18	396-11311-04	CYLINDER, left	1		
1-19	396-11311-04	CYLINDER, right	1		
1-20	183-11181-00	GASKET, cylinder head	2		
1-21	416-11111-00	HEAD, cylinder	2		
1-22	90176-06002	NUT (126-11171-60)	8		
1-23	92901-06200	WASHER, plain	8		
1-24	120-15371-00	BREATHER	1		
1-25	90446-06008	PIPE (248-15373-00 5-150) ..	1		
1-26	241-15357-00	GROMMET	1		
1-27	94701-00045	PLUG, spark (B-8ES)	2		
1-28	92503-06008	SCREW, panhead	2		
1-29	90430-06011	GASKET (137-13167-00)	2		


Fig. 2 CRANKCASE COVER



CRANKCASE COVER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
2- 1	396-15410-00	CRANKCASE COVER ASS'Y, left	1		
2- 2	183-15418-01	, COVER, chain case	1		
2- 3	90266-06005	, RIVET (183-15448-00)	1		
2- 4	307-18188-00	, SHAFT	1		
2- 5	91609-30014	, PIN, spring	1		
2- 6	241-16341-01	, SCREW, push	1		
2- 7	93104-11028	, OIL SEAL (SO-10.5-15-3) ..	1		
2- 8	241-16342-00	, LEVER, push	1		
2- 9	90506-10019	, SPRING, 132-16345-00	1		
2-10	132-16346-00	, HOOK, spring	1		
2-11	92506-06035	SCREW, panhead	2		
2-12	92506-06060	SCREW, panhead	1		
2-13	92506-06120	SCREW, panhead	1		
2-14	396-15417-00	COVER, cap	1		
2-15	98506-05012	SCREW, panhead	2		
2-16	389-15415-00	COVER, generator	1		
2-17	92506-06020	SCREW, panhead	3		
2-18	389-15425-00	COVER	1		
2-19	396-15421-00	COVER, crankcase right	1		
2-20	252-15451-00	GASKET, crankcase cover right	1		
2-21	91810-02015	PIN, dowel (6.5-10-15)	2		
2-22	92506-06030	SCREW, panhead	7		
2-23	92506-06040	SCREW, panhead	1		
2-24	389-15416-00	COVER, oil pump	1		
2-25	389-15426-00	COVER	1		
2-26	92506-06035	SCREW, panhead	3		
2-27	307-15363-00	PLUG, oil	1		

Fig. 3 CRANK · PISTON




CRANK · PISTON

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
3- 0-1	416-11400-00	CRANK ASS'Y	1		
3- 1	183-11412-02	. CRANK 1, left	1		
3- 2	132-11422-03	. CRANK 1, right	1		
3- 3	132-11432-03	. CRANK 2, left	1		
3- 4	389-11442-00	. CRANK 2, right	1		
3- 5	416-11651-00	. ROD, connecting	2		
3- 6	93310-41809	. BEARING	2		
3- 7	122-11681-00	. PIN, crank	2		
3- 8	90209-18112	. WASHER (132-11685-00) ...	4		
3- 9	132-11561-00-03	. SHIM, crank inside (25.5-35-0.3)	2		
3-10	93306-20526	. BEARING (B6205C4 special)	2		
3-11	93450-52010	. CIRCLIP	1		
3-12	132-11511-02	. COVER, crank	1		
3-13	93604-18058	. PIN, dowel (4-17.8)	2		
3-14	183-11512-00	. SEAL, crank cover	2		
3-15	307-11541-00	. METAL, filter	1		
3-16	93210-48045	. O-RING (1.8-4.8)	1		
3-17	132-11515-01	. SEAL, labyrinth	1		
3-18	136-11561-00-03	SHIM, crank outside (20.5-30-0.3)	} U.R. 2		
	136-11561-00-04	SHIM, crank outside (20.5-30-0.4)			
	136-11561-00-05	SHIM, crank outside (20.5-30-0.5)			
	136-11561-00-06	SHIM, crank outside (20.5-30-0.6)			
	136-11561-00-07	SHIM, crank outside (20.5-30-0.7)			
	136-11561-00-08	SHIM, crank outside (20.5-30-0.8)			
3-19	93306-30405	BEARING (B6304C3 special) ..	2		
3-20	93102-20117	OIL SEAL (SD-20-40-8)	1		



Fig. 3 CRANK · PISTON



REPUESTOS
Bratschi
CATERPILLAR


CRANK · PISTON

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
3-21	93103-28011	OIL SEAL (SW-28-40-8)	1		
3-22	93210-18023	O-RING (1.2-17.6)	1		
3-23	90387-20163	COLLAR (183-16136-00)	1		
3-24	389-16111-00	GEAR, primary drive (19T) ..	1		
3-25	90208-12015	SPRING (164-16119-00)	1		
3-26	90179-12044	NUT (353-16144-00)	1		
3-27	466-11631-01-97	PISTON (42.97mm STD) ...	2	U, R	
	466-11631-01-98	PISTON (42.98mm STD) ...			
	466-11635-01	PISTON (43.25mm 1st O.S) ...	2		Alternate Parts
	466-11636-01	PISTON (43.50mm 2nd O.S) ...	2		Alternate Parts
	466-11637-01	PISTON (43.75mm 3rd O.S)	2		Alternate Parts
	466-11638-01	PISTON (44.00mm 4th O.S)	2		Alternate Parts
3-28	183-11633-00	PIN, piston	2		
3-29	93450-13022	CIRCLIP (132-11634-00)	4		
3-30	307-11601-01	PISTON RING SET (STD)	2#		
	307-11601-11	PISTON RING SET (1st O.S) ..	2#		Alternate Parts
	307-11601-21	PISTON RING SET (2nd O.S) ..	2#		Alternate Parts
	307-11601-31	PISTON RING SET (3rd O.S)	2#		Alternate Parts
	307-11601-41	PISTON RING SET (4th O.S)	2#		Alternate Parts
3-31	93310-11296	BEARING	2		
3-32	90280-03017	KEY (146-11545-00)	1		
3-33	90282-05005	KEY (353-11546-00)	1		

ALTERNATE PARTS

3- 0-2	466-11630-00	PISTON ASS'Y (STD)	2	} Ref. No. 27, 28, 29, 30
	466-11630-10	PISTON ASS'Y (1st O.S)	2	
	466-11630-20	PISTON ASS'Y (2nd O.S)	2	
	466-11630-30	PISTON ASS'Y (3rd O.S)	2	
	466-11630-40	PISTON ASS'Y (4th O.S)	2	

Fig. 4 CLUTCH




REPUESTOS
Bratschi
AUTOMOTORES

CLUTCH

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
4- 0-1	307-16301-00	CLUTCH ASS'Y	1		
4- 1	307-16150-00	. PRIMARY DRIVEN GEAR COMP. (74T)	1		
4- 2	132-16369-00	. RING, friction	1		
4- 3	93341-22302	. BEARING, thrust	1		
4- 4	131-16154-00	. PLATE, thrust (17.2-37-2.0)	1		
4- 5	132-16371-02	. BOSS, clutch	1		
4- 6	336-16324-00	. PLATE, clutch	5		
4- 7	307-16367-00	. RING, cushion	5		
4- 8	307-16321-00	. PLATE, friction	5		
4- 9	132-16351-00	. PLATE, pressure	1		
4-10	90501-20125	. SPRING (132-16333-00)	5		
4-11	90149-05057	. SCREW (137-16337-01)	5		
4-12	90208-12015	SPRING (164-16119-00)	1		
4-13	90170-12060	NUT (137-16377-00)	1		
4-14	137-16356-00	ROD, push 1	1		
4-15	183-16181-01	SPACER	1		
4-16	132-15631-00	GEAR, kick pinion (19T)	1		
4-17	122-16164-00	PLATE, thrust (17.2-30-2.0)	1		
4-18	93501-04011	BALL (1/4 inch)	1		
4-19	307-16357-00	ROD, push 2	1		
4-20	95301-06700	NUT	1		
4-21	90113-06013	BOLT, set (241-16343-00)	1		


Fig. 5 TRANSMISSION



TRANSMISSION

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
5- 1	307-17410-00	MAIN AXLE ASS'Y	1		
5- 2	183-17411-00	. AXLE, main (11T)	1		
5- 3	183-17151-00	. GEAR, 5th pinion (25T)	1		
5- 4	90201-20266	. WASHER (132-17216-00) ...	1		
5- 5	93440-20043	. CIRCLIP (132-17414-00) ...	1		
5- 6	307-17141-00	. GEAR, 4th pinion (22T)	1		
5- 7	307-17131-00	. GEAR, 3rd pinion (20T)	1		
5- 8	183-17121-01	. GEAR, 2nd pinion (16T)	1		
5- 9	164-17427-00-08	SHIM, drive axle (15.2-30-0.8)	1	U.R	
	164-17427-00-10	SHIM, drive axle (15.2-30-1.0)			
	164-17427-00-12	SHIM, drive axle (15.2-30-1.2)			
5-10	93315-31502	BEARING	2		
5-11	132-15389-00	SEAL, push rod	1		
5-12	93306-30304	BEARING (B6303Z)	1		
5-13	307-17471-00	PLATE, bearing cover	1		
5-14	92501-06012	SCREW, panhead	2		
5-15	183-17421-00	AXLE, drive	1		
5-16	307-17221-01	GEAR, 2nd wheel (29T)	1		
5-17	307-17231-00	GEAR, 3rd wheel (26T)	1		
5-18	307-17241-00	GEAR, 4th wheel (23T)	1		
5-19	93440-20043	CIRCLIP (132-17414-00)	3		
5-20	90201-20266	WASHER (132-17216-00)	3		
5-21	183-17251-00	GEAR, 5th wheel (21T)	1		
5-22	307-17211-01	GEAR, 1st wheel (35T)	1		
5-23	90201-25290	WASHER (131-15653-00)	1		
5-24	131-15643-00	WASHER, wave	1		
5-25	183-15651-00	GEAR, kick idle (28T)	1		


Fig. 5 TRANSMISSION



TRANSMISSION

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
5-26	164-17427-00-08	SHIM, drive axle (15, 2-30-0, 8)	1	U, R	
	164-17427-00-10	SHIM, drive axle (15, 2-30-1, 0)			
	164-17427-00-12	SHIM, drive axle (15, 2-30-1, 2)			
5-27	93410-15005	CIRCLIP (S-15)	1		
5-28	90560-20038	SPACER (248-17429-00)	1		
5-29	93306-30401	BEARING (B6304)	1		
5-30	93102-28021	OIL SEAL (SD-28-44-7)	1		
5-31	90387-20346	COLLAR (102-17462-00)	1		
5-32	174-17461-30	SPROCKET, drive (13T)	1	U, R	STD
	174-17461-40	SPROCKET, drive (14T)			
	174-17461-50	SPROCKET, drive (15T)			
	174-17461-60	SPROCKET, drive (16T)			
5-33	90179-16018	NUT (102-17463-00)	1		
5-34	90215-16020	WASHER (102-17464-00)	1		


Fig. 6 SHIFTER 1



SHIFTER 1

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
6- 0-1	183-18500-02	SHIFTER ASS'Y	1		
6- 1	183-18541-02	CAM, shift	1		
6- 2	183-18511-00	FORK, shift 1	1		
6- 3	90250-10020	PIN (164-18552-01)	3		
6- 4	164-18551-00	ROLLER, cam follow	3		
6- 5	91401-25020	PIN, cotter	3		
6- 6	183-18512-00	FORK, shift 2	1		
6- 7	183-18513-00	FORK, shift 3	1		
6- 8	93604-22050	PIN, dowel (4-21.8)	4		
6- 9	90249-04039	PIN (174-18544-00)	1		
6-10	93430-03014	CIRCLIP (E-2.5)	1		
6-11	164-18561-00	PLATE, side	1		
6-12	98501-05012	SCREW, panhead	1		
6-13	92901-05100	WASHER, spring	1		
6-14	132-18140-01	STOPPER LEVER ASS'Y	1		
6-15	90109-06001	BOLT (132-18177-00)	1		
6-16	90506-09112	SPRING, tension	1		
6-17	90201-12166	WASHER (164-18572-00)	1		
6-18	307-18571-00	HOLDER, shift cam	2		
6-19	93440-15012	CIRCLIP	1		
6-20	307-18533-00	PLUG, blind	1		
6-21	93505-16006	BALL (5/16 inch)	1		
6-22	90501-12083	SPRING (174-18558-00)	1		
6-23	137-15353-00	GASKET (14.5-21-15)	1		
6-24	90109-14385	BOLT	1		


Fig.7 SHIFTER 2



SHIFTER 2

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
7- 1	307-18101-01	CHANGE SHAFT ASS'Y	1		
7- 2	90506-09009	- SPRING (132-18123-00)	1		
7- 3	90508-32207	SPRING (132-18124-00)	1		
7- 4	90149-08094	SCREW	1		
7- 5	95301-08600	NUT, hexagon	1		
7- 6	93101-12004	OIL SEAL (S-12-22-5)	1		
7- 7	90201-12183	WASHER (132-18137-00)	1		
7- 8	93430-10016	CIRCLIP (E-10)	1		
7- 9	307-18111-00-93	PEDAL, change	1		
7-10	132-18113-01	COVER, change pedal	1		
7-11	90201-12174	WASHER (183-22142-10)	1		
7-12	93430-10016	CIRCLIP (E-10)	1		
7-13	91401-16012	PIN, cotter	2		
7-14	90240-08013	PIN (307-18116-00)	2		
7-15	326-18115-00	ROD, change	1		
7-16	90201-08085	WASHER (141-18139-00)	2		
7-17	307-18112-00-93	ARM, change	1		
7-18	91101-06030	BOLT	1		


Fig. 8 KICK STARTER



KICK STARTER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
8- 1	278-15611-00-93	CRANK, kick	1		
8- 2	156-15618-01	COVER, kick lever	1		
8- 3	90501-12081	SPRING (278-15622-00)	1		
8- 4	93507-32009	BALL (7/32 inch)	1		
8- 5	337-15621-01-91	BOSS, kick crank	1		
8- 6	97311-06025	BOLT	1		
8- 7	90201-15234	WASHER (278-15613-00)	1		
8- 8	93430-10016	CIRCLIP (E-10)	1		
8- 9	93109-15001	OIL SEAL (SDO-15-26-6)	1		
8-10	93410-15005	CIRCLIP (S-15)	1		
8-11	132-15676-00	COVER, kick spring	1		
8-12	90508-26136	SPRING (304-15665-00)	1		
8-13	132-15664-00	GUIDE, kick spring	1		
8-14	93410-25017	CIRCLIP (S-25)	1		
8-15	117-15644-00	SHIM (25.1-32-1.0)	1		
8-16	180-15641-00	GEAR, kick (28T)	1		
8-17	180-15687-00	CLIP, kick	1		
8-18	180-15660-00	KICK AXLE ASS'Y	1		


Fig.9 TACHOMETER GEAR



TACHOMETER GEAR

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
9- 1	237-17861-00	AXLE, drive gear	1		
9- 2	248-17831-01	GEAR, drive	1		
9- 3	248-17837-00	SHIM (10.2-16-1.0)	2		
9- 4	248-17841-00	GEAR, driven	1		
9- 5	93210-13016	O-RING (1.8-13)	1		
9- 6	214-17811-01	HOUSING	1		
9- 7	93210-07100	O-RING (2.2-7.2)	1		
9- 8	214-17847-00	SHIM (7.5-10.8-0.4)	1		
9- 9	90383-10005	BUSHING (214-17815-00)	1		
9-10	214-17812-00	STOPPER	1		
9-11	92501-06010	SCREW, panhead	1		
9-12	92901-06100	WASHER, spring	1		
9-13	214-17843-00	BUSHING	1		


Fig. 10 INTAKE



SCOOTER INTAKE

Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
10- 1	397-14411-00	CASE, air cleaner	1		
10- 2	396-14451-00	ELEMENT, air cleaner	2		
10- 3	389-14412-01	CAP, cleaner case left	1		
10- 4	397-14422-00	CAP, cleaner case right	1		
10- 5	92901-06200	WASHER, plain	2		
10- 6	92501-06010	SCREW, panhead	2		
10- 7	92501-06080	SCREW, panhead	1		
10- 8	92901-06100	WASHER, spring	2		
10- 9	92501-06070	SCREW, panhead	1		
10-10	389-14453-00	JOINT, air cleaner left	1		
10-11	389-14463-00	JOINT, air cleaner right	1		
10-12	90460-49058	BAND (278-14455-00)	2		
10-13	90460-37026	BAND (396-14456-00)	2		
10-14	389-13610-01	REED VALVE ASS'Y	2		
10-15	389-13613-00	REED VALVE	4		
10-16	389-13616-01	STOPPER, reed valve	4		
10-17	98512-03008	SCREW, panhead	8		
10-18	92901-03100	WASHER, spring	8		
10-19	389-13621-00	PACKING, valve seat	4		
10-20	389-13555-00	JOINT	2		
10-21	389-13622-00	PACKING, carburetor	2		
10-22	92706-06025	SCREW, flathead	8		
10-23	91316-08040	BOLT	4		
10-24	92906-08100	WASHER, spring	4		
10-25	92906-08200	WASHER, plain	4		

Fig. 11 CARBURETOR




CARBURETOR

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
11- 0-1	507-14301-60	CARBURETOR ASS'Y, left ..	1		
11- 0-2	507-14302-60	CARBURETOR ASS'Y, right ..	1		
11- 1	367-14342-22	. JET, pilot (#44)	2		
11- 2	396-14341-00	. NOZZLE, main (N-80)	2		
11- 3	396-14343-46	. JET, main (#92)	2		
11- 4	396-14390-16	. VALVE SEAT ASS'Y	2		
11- 5	367-14195-00	. WASHER, valve seat	2		
11- 6	367-14385-00	. FLOAT	2		
11- 7	367-14386-00	. PIN, float	2		
11- 8	397-14181-00-33	. BODY, float chamber	1		
	397-14183-00-33	. BODY, float chamber	1		
11- 9	389-14384-00	. GASKET, float chamber ...	2		
11-10	98501-04010	. SCREW, panhead	8		
11-11	92901-04100	. WASHER, spring	8		
11-12	389-14147-00	. O-RING	1		
11-13	396-14371-00	. PLUNGER, starter	1		
11-14	389-14335-00	. SPRING, plunger	1		
11-15	389-14138-00	. PIN, snap	1		
11-16	396-14374-00	. CAP, plunger	1		
11-17	389-14373-00	. COVER, plunger cap	1		
11-18	389-14261-01	. KNOB, starter	1		
11-19	396-14211-00	. SCREW, pilot adjusting	2		
11-20	389-14212-00	. SPRING, pilot adjusting	2		
11-21	396-14323-00	. SCREW, air adjusting	2		
11-22	389-14333-00	. SPRING, air adjusting	2		
11-23	396-14312-20	. VALVE, throttle left	1		
	396-14313-20	. VALVE, throttle right	1		
11-24	396-14336-00	. NEEDLE (4D50-2)	2		
11-25	389-14137-00	. CLIP, needle	2		
11-26	396-14136-00	. SEAT, spring	2		




Fig. 11 CARBURETOR



CARBURETOR

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
11-27	396-14331-00	. SPRING, throttle valve	2		
11-28	389-14126-00	. PACKING	2		
11-29	389-14168-00-33	. CAP, mixing chamber	2		
11-30	288-14161-00	. NUT, wire adjusting	2		
11-31	396-14124-00	. SCREW, wire adjusting	2		
11-32	367-14169-00	. CAP	2		
11-33	396-14348-00	. PIPE (3-220)	2		
11-34	389-14396-00	. PIPE (3-160)	2		
11-35	389-14349-00	. PIPE (5-47)	1		
11-36	91690-20008	. PIN, spring	1		


Fig. 12 EXHAUST



EXHAUST

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
12- 1	396-14611-00	PIPE, exhaust left	1		
12- 2	396-14621-00	PIPE, exhaust right	1		
12- 3	307-14612-00	NUT, ring	2		
12- 4	132-14613-00	GASKET, exhaust pipe	2		
12- 5	90116-08166	STUD	4		
12- 6	92901-08100	WASHER, spring	4		
12- 7	95301-08600	NUT, hexagon	4		
12- 8	466-14710-01	MUFFLER, left	1		
12- 9	466-14720-01	MUFFLER, right	1		
12-10	307-14753-00	. SILENCER	2		
12-11	98501-05010	. SCREW, panhead	2		
12-12	92901-05100	. WASHER, spring	2		
12-13	396-14771-00	. STAY, muffler left	1		
12-14	396-14781-00	. STAY, muffler right	1		
12-15	95301-08600	. NUT, hexagon	4		
12-16	92901-08100	. WASHER, spring	4		
12-17	132-14713-00	NUT, muffler joint	2		
12-18	132-14714-01-00	GASKET, muffler joint	2		
12-19	102-27114-00	STOPPER, main stand	1		
12-20	92901-08100	WASHER, spring	2		
12-21	95301-08600	NUT, hexagon	2		


Fig. 13 OIL PUMP



OIL PUMP


Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
13- 1	126-13116-00	GASKET, pump case	1		
13- 2	256-17837-00	SHIM	1		
13- 3	174-13175-00	SHAFT, worm	1		
13- 4	93603-22028	PIN, dowel (3-21.8)	1		
13- 5	137-13176-00	METAL, worm shaft outer ...	1		
13- 6	93101-10002	OIL SEAL (S-10-22-7)	1		
13- 7	132-13178-01	GEAR, drive (34T)	1		
13- 8	92901-08400	WASHER, tooth	1		
13- 9	95301-08700	NUT, hexagon	1		
13-10	98501-05015	SCREW, panhead	2		
13- 0-1	416-13101-00	OIL PUMP ASS'Y	1		
13-11	137-13137-00-03	. SHIM (5.8-10-0.3)	1	U. R	
	137-13137-00-05	. SHIM (5.8-10-0.5)			
	137-13137-00-10	. SHIM (5.8-10-1.0)			
	137-13137-00-30	. SHIM (5.8-10-3.0)			
	137-13137-00-50	. SHIM (5.8-10-5.0)			
13-12	137-13138-01	. PLATE, adjusting	1		
13-13	402-13146-00	. COVER	1		
13-14	92901-05100	. WASHER, spring	1		
13-15	95301-05600	. NUT	1		
13-16	93101-10001	. OIL SEAL (S-10-21-5)	1		
13-17	137-13128-00	. PLATE, starter	1		
13-18	91401-12018	. PIN, cotter	1		
13-19	93505-32002	. BALL (5/32 inch)	2		
13-20	90501-02018	. SPRING (278-13169-00)	2		
13-21	353-13552-01	. NOZZLE	2		
13-22	90468-02033	. CLIP (214-13164-00)	2		
13-23	98901-04008	. SCREW, blind	1		
13-24	90430-04004	. GASKET (137-13187-00)	1		

Fig. 13 OIL PUMP



ROTARY OIL PUMP

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
13-25	278-13161-00	. PIPE, delivery (3-420)	1		
13-26	90445-05217	. PIPE (353-13161-00 3-240)	1		
13-27	90468-02033	CLIP (214-13164-00)	2		
13-28	293-13174-00	HOLDER, oil pipe	1		



A.C.GENERATOR


Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
14- 0-1	307-81400-10	A.C. GENERATOR ASS'Y	1		
14- 1	307-81450-10	. ROTOR ASS'Y	1		
14- 2	307-81410-10	. STATOR ASS'Y	1		
14- 3	183-81421-10	. CONTACT BREAKER ASS'Y	2		
14- 4	165-81145-21	. SCREW, panhead	7		
14- 5	92901-04100	. WASHER, spring	8		
14- 6	92901-04200	. WASHER, plain	5		
14- 7	183-81425-10	. CONDENSER	2		
14- 8	183-81431-10	. LUBRICATOR	1		
14- 9	110-81345-20	. SCREW, panhead	1		
14-10	183-81432-10	. PLATE, timing	1		
14-11	183-81451-12	. CAM	1		
14-12	90143-07022	. BOLT (307-81452-00)	1		
14-13	92901-08100	. WASHER, spring	1		
14-14	92501-06075	. SCREW, panhead	3		
14-15	92901-06100	. WASHER, spring	3		

CHASSIS



YAMAHA
PARTS

Fig. 15 FRAME




FRAME

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
15- 1	396-21110-01-33	FRAME COMP.	1		Yamaha Black
15- 2	307-21315-00-33	STAY, engine front	2		Yamaha Black
15- 3	95821-08055	BOLT	4		
15- 4	95701-08100	NUT	5		
15- 5	92901-08100	WASHER, spring	5		
15- 6	95821-08110	BOLT	1		
15- 7	90105-08026	BOLT	1		
15- 8	803-82591-00	BAND	1		
15- 9	307-21165-00-33	HANDLE, standing	1		Yamaha Black
15-10	396-28100-11	TOOL ASS'Y	1		



Fig.16 SIDE COVER · BOX




SIDE COVER · BOX

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
16- 1	396-21711-01-M3	COVER, side	1		Baja Brown
	396-21711-01-G6	COVER, side	1		Balboa Blue
16- 2	92501-06015	SCREW, panhead	1		
16- 3	92901-06100	WASHER, spring	1		
16- 4	396-21782-01	MOLD, right	1		
16- 5	90183-03006	NUT (360-24143-00)	2		
16- 6	416-21717-00	DAMPER, side cover	1		
16- 7	466-21717-00	DAMPER, side cover	1		
16- 8	466-21778-01	BRACKET, spring l.	1		
16- 9	92501-06008	SCREW, panhead	1		
16-10	92901-06100	WASHER, spring	1		
16-11	466-21783-20	EMBLEM 125	1		
16-12	396-21170-00-33	BOX COMP.	1		Yamaha Black
16-13	97301-06070	BOLT, hexagon	1		
16-14	92901-06100	WASHER, spring	1		
16-15	92901-06600	WASHER, plate	1		
16-16	97301-06045	BOLT, hexagon	2		
16-17	92901-06100	WASHER, spring	2		
16-18	95301-06600	NUT, hexagon	2		
16-19	307-82121-00	PAD, battery	1		



Fig. 17 REAR ARM · REAR CUSHION · CHAIN CASE




REAR ARM · REAR CUSHION · CHAIN CASE

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
17- 1	507-22110-00-33	REAR ARM COMP.	1		Yamaha Black
17- 2	307-22123-00	BUSHING, rear arm	2		
17- 3	307-22141-70	SHAFT, pivot	1		
17- 4	90170-12065	NUT (183-25182-00)	1		
17- 5	173-22151-00	SEAL, guard	1		
17- 6	164-22216-00	BUSHING, rear cushion	2		
17- 7	307-22210-00-M3	REAR CUSHION ASS'Y	2		Beja Brown
	307-22210-00-G6	REAR CUSHION ASS'Y	2		Balboa Blue
17- 8	90176-10013	NUT, cap	2		
17- 9	90201-10140	WASHER (102-22243-00)	2		
17-10	90201-14218	WASHER (135-22243-00)	2		
17-11	90106-08027	BOLT	2		
17-12	307-22311-00-93	CHAIN CASE, half	1		
17-13	90149-06012	SCREW (183-22331-01)	1		
17-14	183-22332-01	DAMPER, chain case	1		
17-15	90201-07079	WASHER (183-22316-01)	1		
17-16	92501-06012	SCREW, panhead	2		
17-17	92901-06100	WASHER, spring	2		
17-18	465-27431-00	FOOTREST, rear	2		
17-19	120-27433-00	COVER, rear footrest	2		
17-20	90201-20279	WASHER, plate	2		
17-21	90240-06042	PIN, with hole	2		
17-22	91401-16012	PIN, cotter	2		
ALTERNATE PARTS					
17-23	396-22210-20	REAR CUSHION ASS'Y	2		



Fig. 18 STAND · FOOTREST · BRAKE PEDAL




STAND · FOOTREST · BRAKE PEDAL

Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
18- 1	307-27111-00	STAND, main	1		
18- 2	122-27112-00	SHAFT, main stand	1		
18- 3	307-27211-10-93	PEDAL, brake	1		
18- 4	93430-12008	CIRCLIP (E-12)	1		
18- 5	90508-32056	SPRING (183-27216-00)	1		
18- 6	307-27115-00	LINK	1		
18- 7	90506-29054	SPRING (122-27116-00)	1		
18- 8	307-27231-00	ROD, brake	1		
18- 9	92901-06600	WASHER, plate	1		
18-10	91401-20012	PIN, cotter	1		
18-11	92901-06600	WASHER, plate	1		
18-12	90501-10245	SPRING (180-27236-00)	1		
18-13	90249-12008	PIN (156-27237-00)	1		
18-14	90179-06176	NUT	1		
18-15	396-27411-01	FOOTREST	1		
18-16	396-27412-00	BRACKET, footrest	1		
18-17	132-27422-00	DAMPER, rubber 2	1		
18-18	132-27414-00	DAMPER, rubber 1	1		
18-19	132-27417-00	WASHER, special	1		
18-20	90109-08193	BOLT (132-27416-00)	3		
18-21	92901-10600	WASHER, plate	3		
18-22	307-27413-00	COVER, footrest	2		
18-23	507-27311-00	STAND, side	1		
18-24	90109-10399	BOLT	1		
18-25	90171-10012	NUT, slotted	1		
18-26	91401-20025	PIN, cotter	1		
18-27	507-27315-01	LINK, side stand	1		
18-28	90507-29022	SPRING	1		
18-29	97301-08020	BOLT	1		
18-30	92901-08100	WASHER, spring	1		



Fig. 19 FRONT FENDER · REAR FENDER



FRONT FENDER · REAR FENDER


Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
19- 1	478-21510-01-93	FRONT FENDER COMP.	1		
19- 2	97301-08010	BOLT	4		
19- 3	92901-08100	WASHER, spring	4		
19- 4	174-21518-00-93	HOLDER, wire	1		
19- 5	95301-06600	NUT, hexagon	1		
19- 6	92901-06100	WASHER, spring	1		
19- 7	307-21610-00-93	REAR FENDER COMP.	1		
19- 8	97301-06050	BOLT	2		
19- 9	92901-06100	WASHER, spring	4		
19-10	92901-06200	WASHER, plain	2		
19-11	97301-06012	BOLT	2		
19-12	90480-12013	GROMMET (152-84518-00) ...	2		



ALTERNATE PARTS

19-13	307-21510-80-93	FRONT FENDER COMP.	1		
19-14	122-21582-81-33	PLATE, license	1		Yamaha Brack
19-15	173-21581-80-93	PLATE, fitting	2		
19-16	97303-06012	BOLT, hexagon	4		
19-17	95303-06600	NUT, hexagon	4		
19-18	92903-06600	WASHER, plain	2		
19-19	92901-06100	WASHER, spring	4		

Fig. 20 FRONT FORK




FRONT FORK

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
20- 0-1	396-23101-00	FRONT FORK ASS'Y	1		
20- 1	396-23126-00-35	. TUBE, outer left	1		Silver
20- 2	307-23136-00-35	. TUBE, outer right	1		Silver
20- 3	307-23141-00	. SPRING, fork	2		
20- 4	252-23149-00	. WASHER, spring upper	2		
20- 5	252-23124-00	. TUBE, inner	2		
20- 6	164-23125-00	. METAL, slide	2		
20- 7	164-23147-00	. O-RING	2		
20- 8	307-23150-01	. OUTER NUT COMP.	2		
20- 9	164-23145-01	. OIL SEAL	2		
20-10	252-23144-00	. SEAL, dust	2		
20-11	307-23122-00-93	. COVER, outer left	1		
20-12	307-23132-00-93	. COVER, outer right	1		
20-13	164-23163-00	. PACKING	2		
20-14	252-23116-00	. COVER, under	2		
20-15	307-23114-00	. PACKING (O-RING)	2		
20-16	183-23112-00	. WASHER, cap	2		
20-17	307-23111-00	. BOLT, cap	2		
20-18	307-23340-00-33	. UNDER BRACKET COMP. ..	1		Yamaha Black
20-19	183-23318-00	. HOLDER, wire	2		
20-20	122-23346-01	. BOLT, under bracket	2		
20-21	92901-10100	. WASHER, spring	2		
20-22	122-23119-01	. PLUG, drain	2		
20-23	122-23129-00	. GASKET, drain plug	2		
20-24	90119-08010	. BOLT (122-23128-00)	1		
20-25	92901-08100	. WASHER, spring	1		
20-26	252-23121-00-M3	COVER, upper left	1		Baja Brown
	252-23121-00-G6	COVER, upper left	1		Balboa Blue




Fig. 20 FRONT FORK



FRONT FORK

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
20-27	252-23131-00-M3	COVER, upper right	1		Baja Brown
	252-23131-00-G6	COVER, upper right	1		Bulbos Blue
20-28	341-85111-00	REFLECTOR	2		
20-29	92901-05100	WASHER, spring	2		
20-30	92901-05200	WASHER, plain	2		

Fig. 21 STEERING




HANDLE · WIRE

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
22- 1	183-26111-10	HANDLE	1		STD
	307-26111-20	HANDLE	1		Bar Alternate Parts
	212-26111-00	HANDLE	1		Bridge Alternate Parts
22- 2	235-26241-10	GRIP, left	1		
22- 3	396-83972-10	SWITCH HANDLE 4	1		
	396-83972-20	SWITCH HANDLE 4	1		Alternate Parts
22- 0-1	214-82910-02	LEVER HOLDER ASS'Y, left ..	1		
22- 4	214-82911-01	. HOLDER, lever left	1		
22- 5	214-83912-00	. LEVER, left	1		
22- 6	97303-06020	. BOLT	2		
22- 7	214-83913-00	. COLLAR, lever	1		
22- 8	95301-06700	. NUT	1		
22- 9	92901-06100	. WASHER, spring	1		
22- 0-2	233-82920-32	LEVER HOLDER ASS'Y, right	1		
22-10	233-82921-31	. HOLDER, lever right	1		
22-11	233-83922-30	. LEVER, right	1		
22-12	97303-06020	. BOLT	1		
22-13	92901-06100	. WASHER, spring	1		
22-14	90109-05197	. BOLT (233-83915-01)	1		
22-15	214-83913-00	. COLLAR, lever	1		
22-16	95301-05900	. NUT, slotted	1		
22-17	92901-05200	. WASHER, plain	1		
22-18	91401-12015	. PIN, cotter	1		
22-19	232-83980-30	FRONT STOP SWITCH ASS'Y ..	1		
22-20	307-26281-00	CAP, grip upper	1		
22-21	307-26282-00	CAP, grip under	1		
22-22	98501-05015	SCREW, panhead	2		
22-23	137-26243-60	TUBE, guide	1		
22-24	306-26242-10	GRIP, right	1		



Fig. 22 HANDLE · WIRE




HANDLE · WIRE

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
22-25	396-26311-10	WIRE, throttle 1 (550mm)	1		STD, Bridge
	396-26311-20	WIRE, throttle 1 (445mm)	1		Bar Alternate Parts
22-26	360-26261-01	CYLINDER, wire	1		
22-27	396-26312-00	WIRE, throttle 2 (235mm)	2		
22-28	396-26321-00	WIRE, pump (350mm)	1		
22-29	396-26335-10	WIRE, clutch (980mm)	1		STD
	396-26335-20	WIRE, clutch (737mm)	1		Bar Alternate Parts
	396-26335-40	WIRE, clutch (955mm)	1		Bridge Alternate Parts
22-30	396-26341-10	WIRE, brake (1090mm)	1		STD, Bridge
	396-26341-20	WIRE, brake (862mm)	1		Bar Alternate Parts
22-31	90123-06010	BOLT (326-26345-00)	1		
22-32	90179-06143	NUT (109-26344-00)	1		
22-33	90123-08046	BOLT (168-26337-00)	2		
22-34	90179-08148	NUT (168-26344-00)	2		
22-35	168-83936-01	BAND, switch cord	3		
22-36	326-26328-00	GUIDE, wire	1		
22-37	92901-06100	WASHER, spring	1		
22-38	95301-06600	NUT, hexagon	1		
22-39	407-26290-60	BACK MIRROR ASS'Y, right ..	1		Convex Mirror
	382-26290-40	BACK MIRROR ASS'Y, right ..	1		Alternate Parts Flat Mirror
22-40	407-26290-50	BACK MIRROR ASS'Y, left ..	1		Alternate Parts Convex Mirror
	382-26290-30	BACK MIRROR ASS'Y, left ..	1		Alternate Parts Flat Mirror



Fig. 23 FUEL TANK




FUEL TANK

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
23- 1	398-24110-Y0-01	FUEL TANK COMP.	1		Baja Brown
	398-24110-Y0-02	FUEL TANK COMP.	1		Balboa Blue
23- 2	397-24254-20	. GRAPHIC, fuel tank upper left	1		
	397-24255-20	. GRAPHIC, fuel tank upper right	1		
23- 3	397-24256-20	. GRAPHIC, fuel tank under left	1		
	397-24257-20	. GRAPHIC, fuel tank under right	1		
23- 4	322-24161-00	. EMBLEM, fuel tank	2		
23- 5	417-24602-00	CAP ASS'Y	1		
23- 6	498-24612-00	. PACKING, cap	1		
23- 7	122-24181-00	DAMPER, locating	2		
23- 8	307-24182-00	DAMPER, locating	1		
23- 9	90445-09083	HOSE (137-24331-00 5-155) ..	2		
23-10	90445-09078	HOSE (132-24311-00 5-190) ..	1		
23-11	90467-08003	CLIP (101-24356-00)	6		
23-12	360-24500-00	FUEL COCK ASS'Y	1		
23-13	360-24521-00	. CUP, filter	1		
23-14	168-24522-00	. GASKET, filter	1		
23-15	360-24515-00	. NET, filter	1		
23-16	92501-06025	. SCREW, panhead	2		
23-17	360-24512-00	. GASKET	2		
23-18	137-24523-00	. VALVE	1		
23-19	168-24512-00	. O-RING	1		



Fig. 24 OIL TANK




OIL TANK

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
24- 1	396-21705-01-M3	OIL TANK ASS'Y	1		Raja Brown
	396-21705-01-G6	OIL TANK ASS'Y	1		Balboa Blue
24- 2	360-21761-00	. GAUGE, level	1		
24- 3	214-21771-00	CAP, oil tank	1		
24- 4	90430-29114	GASKET (214-21772-00)	1		
24- 5	307-24319-00	PIPE, oil (5-500)	1		
24- 6	90467-08003	CLIP (101-24356-00)	2		
24- 7	92501-06012	SCREW, panhead	1		
24- 8	92901-06100	WASHER, spring	1		
24- 9	92501-06015	SCREW, panhead	2		
24-10	92901-06100	WASHER, spring	2		
24-11	90445-08047	HOSE (168-82112-00 5-580) ..	1		
24-12	396-21781-01	MOLD, left	1		
24-13	90183-03006	NUT (360-24143-00)	2		
24-14	466-21783-20	EMBLEM 125	1		



Fig. 25 SEAT



SEAT

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
25- 1	396-24730-02	DOUBLE SEAT ASS'Y	1		
25- 1-1	396-24731-00	COVER, double seat	1		
25- 2	389-24726-00-33	HINGE, seat	2		Yamaha Black
25- 3	91501-05055	PIN, clevis	2		
25- 4	389-24756-00	STOPPER	2		
25- 5	92501-06010	SCREW, panhead	2		
25- 6	92901-06100	WASHER, spring	2		
25- 7	97301-06012	BOLT	8		
25- 8	92901-06100	WASHER, spring	7		
25- 9	353-24705-04	SEAT LEVER ASS'Y	1		
25-10	92901-06600	WASHER, plain	1		
25-11	278-24728-00	BRACKET, seat	1		
25-12	276-24748-00	BRACKET, seat stopper	1		
25-13	337-24768-00	STOPPER, seat	1		
25-14	174-24741-00	PAD, seat	5		



OPTIONAL PARTS


25-15	307-24830-01	SUB CARRIER ASS'Y	1		
25-16	92901-06600	WASHER, plate	2		

FRONT WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
26- 1	307-25111-00	HUB, front	1		
26- 0-1	307-25104-00	SPOKE SET	1s		
26- 2	307-25196-90	. SPOKE SET, inner (10PCS) ...	1s		
26- 3	307-25197-90	. SPOKE SET, outer (10PCS) ...	1s		
26- 4	94414-18095	RIM (1.40-18)	1		
26- 5	94125-18019	TIRE, front (2.50-18-4PR) ...	1		
26- 6	94225-18006	TUBE (2.50-18)	1		
26- 7	94327-18008	BAND, rim	1		
26- 8	90560-12138	SPACER (183-25117-00)	1		
26- 9	109-25315-00	FLANGE, spacer	1		
26-10	93306-30103	BEARING (B6301Z)	2		
26-11	93102-18008	OIL SEAL (SD-18-37-8)	1		
26-12	307-25121-00	PLATE, brake shoe	1		
26-13	90201-20269	WASHER (183-25147-00)	2		
26-14	307-25135-00	GEAR, drive	1		
26-15	183-25149-00	CLUTCH, meter	1		
26-16	93410-20009	CIRCLIP (S-20)	1		
26-17	307-25130-00	BRAKE SHOE COMP.	2		
26-18	90506-16036	SPRING (183-25333-00)	2		
26-19	93105-47007	OIL SEAL (SOD-47-58-7)	1		
26-20	183-25351-00	CAMSHAFT	2		
26-21	307-25138-00	GEAR, meter	1		
26-22	90201-07076	WASHER (183-25146-00)	1		
26-23	109-25136-00	BUSHING	1		
26-24	93104-07003	OIL SEAL (SD-7-14-4)	1		
26-25	93210-14104	O-RING	1		
26-26	102-25137-00	RING, stopper	1		
26-27	307-25155-00	LEVER, camshaft 1	1		
26-28	307-25156-00	LEVER, camshaft 2	1		



Fig. 26 FRONT WHEEL




FRONT WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
26-29	97301-06030	BOLT, hexagon	2		
26-30	95301-06600	NUT, hexagon	2		
26-31	90387-12095	COLLAR (183-25183-00)	1		
26-32	183-25118-00	COVER hub dust	1		
26-33	90387-12099	COLLAR (251-25186-00)	1		
26-34	382-25181-01	SHAFT, wheel	1		
26-35	92901-12100	WASHER, spring	1		
26-36	90171-12005	NUT (367-25382-00)	1		
26-37	152-25163-00	ROD, end	1		
26-38	95301-06700	NUT, hexagon	1		
26-39	307-25161-00	ROD, connecting	1		
26-40	90249-06095	PIN (152-25165-00)	2		
26-41	93430-04003	CIRCLIP (E-4)	2		
26-42	91401-30022	PIN, cotter	1		



Fig. 27 REAR WHEEL




REAR WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
27- 1	183-25311-00	HUB, rear	1		
27- 0-1	183-25304-00	SPOKET SET	1#		
27- 2	183-25396-90	. SPOKET SET, inner (10PCS)..	1#		
27- 3	183-25397-90	. SPOKET SET, outer (10PCS)..	1#		
27- 4	94127-18064	TIRE, rear (2.75-18-4PR)	1		
27- 5	94227-18009	TUBE (2.75-18)	1		
27- 6	94416-18018	RIM (1.60-18)	1		
27- 7	94327-18008	BAND, rim (2.75-18)	1		
27- 8	90560-15136	SPACER (136-25317-00)	1		
27- 9	183-25315-00	FLANGE, spacer	1		
27-10	93306-20205	BEARING (B6202)	1		
27-11	93104-22018	OIL SEAL (SD-22-35-5)	1		
27-12	93306-20204	BEARING (B6202Z)	1		
27-13	93210-42101	O-RING	1		
27-14	304-25364-00	DAMPER, clutch	4		
27-15	183-25321-00	PLATE, brake shoe	1		
27-16	183-25351-00	CAMSHAFT	1		
27-17	183-25330-01	BRAKE SHOE COMP.	2		
27-18	90506-16036	SPRING (183-25333-00)	2		
27-19	307-25355-00	LEVER, camshaft	1		
27-20	97301-06025	BOLT, hexagon	1		
27-21	95301-06600	NUT	1		
27-22	183-25387-00	SHAFT, sprocket	1 ¹		
27-23	183-25366-01	CLUTCH, hub	1		
27-24	183-25437-10	GEAR, sprocket wheel (37T)	} U.R. 1		
	183-25438-10	GEAR, sprocket wheel (38T)			
	183-25439-10	GEAR, sprocket wheel (39T)			STD
27-25	90109-08057	BOLT (102-25411-01)	4		
27-26	102-25412-00	WASHER, lock	2		



Fig. 27 REAR WHEEL




REAR WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
27-27	90170-08157	NUT, hexagon	4		
27-28	382-25381-01	SHAFT, wheel	1		
27-29	91401-30030	PIN, cotter	1		
27-30	248-25388-00	PULLER, chain	1		
27-31	90387-15425	COLLAR (183-25383-00)	1		
27-32	93306-00406	BEARING (B6004Z)	1		
27-33	93420-42007	CIRCLIP (R-42)	1		
27-34	93106-26005	OIL SEAL (SDD-26-42-8)	1		
27-35	90387-20165	COLLAR (183-25386-00)	1		
27-36	214-25388-00	PULLER, chain	1		
27-37	90170-20167	NUT	1		
27-38	90171-14006	NUT (214-25182-01)	1		
27-39	90101-08034	BOLT (168-25379-00)	2		
27-40	95301-08700	NUT, hexagon	2		
27-41	307-25371-00	BAR, tension	1		
27-42	90109-08063	BOLT (109-25373-00)	1		
27-43	95301-08700	NUT	1		
27-44	92901-08100	WASHER, spring	2		
27-45	90468-12007	CLIP (102-25375-00)	1		
27-46	90109-08368	BOLT (183-25378-00)	1		
27-47	95301-08600	NUT	1		
27-48	91401-20012	PIN, cotter	1		
27-49	94504-28110	CHAIN (DK428-110L)	1		
27-50	94604-28001	JOINT, chain	1		



Fig. 28 HEAD LAMP




HEAD LAMP

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
28- 1	237-84330-60-M3	HEAD LAMP BODY ASS'Y	 1		Baja Brown
	237-84330-60-G6	HEAD LAMP BODY ASS'Y	 1		Balboa Blue
28- 2	214-84153-60	. GROMMET	 1		
28- 0-1	252-84310-00	HEAD LAMP UNIT ASS'Y	... 1		
28- 3	237-84315-00	. RIM, head lamp	 1		
28- 4	237-84320-00	. LENS ASS'Y	 1		
28- 5	195-84324-00	. SPRING, reflector set	 4		
28- 6	183-84314-60	. BULB, head lamp (12V-35/35W)	1		
28- 7	252-84312-00	. SOCKET	 1		
28- 8	195-84325-00	SCREW, rim fitting	 1		
28- 0-2	256-84301-61	PILOT LAMP ASS'Y	 1		
28- 9	256-84357-61	. BODY, pilot lamp	 1		
28-10	256-84347-00	. BULB, pilot (12V-2W)	 1		
28-11	256-84350-61	. SOCKET CORD ASS'Y	 1		



Fig. 29 SPEEDOMETER · TACHOMETER






SPEEDOMETER · TACHOMETER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
29- 1	396-83510-20	SPEEDOMETER ASS'Y	1		Km/h
	396-83510-40	SPEEDOMETER ASS'Y	1		Mile/h
29- 2	123-83516-20	. BULB (12V-3W)	1		
29- 3	235-83536-21	. SOCKET, meter	1		
29- 4	214-83513-00	. DAMPER, meter	1		
29- 5	396-83585-00	LABEL, speedometer	1		Destined for New Zealand
29- 6	396-83540-00	TACHOMETER ASS'Y	1		
29- 7	123-83516-20	. BULB (12V-3W)	3		
29- 8	252-83520-01	. SOCKET ASS'Y	1		
29- 9	214-83513-00	. DAMPER, meter	1		
29-10	337-83519-00-33	BRACKET, meter	1		
29-11	214-83523-00	DAMPER	1		
29-12	237-83523-00	DAMPER	1		
29-13	90209-05029	WASHER (214-83524-00)	4		
29-14	90468-10050	CLIP (156-83525-00)	4		
29-15	252-83550-00	SPEEDOMETER CABLE ASS'Y ..	1		
29-16	396-83560-00	TACHOMETER CABLE ASS'Y ..	1		
29-17	97301-08015	BOLT	2		
29-18	92901-08100	WASHER, spring	2		



Fig. 30 TAIL LAMP

EXCLUSIVE PARTS FOR AUSTRALIA



OPTIONAL PARTS






TAIL LAMP

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
30- 0-1	341-84710-00	TAIL LAMP UNIT ASS'Y	1		
30- 1	306-84711-60	. BASE, tail lamp	1		
30- 2	275-84523-60	. GASKET, tail lens	1		
30- 3	137-84714-61	. BULB, tail lamp (12V-23/8W)	1		
30- 4	341-84721-00	. LENS, tail lamp	1		
30- 5	341-84724-60	. SCREW, lens fitting	3		
30- 6	341-84722-60	. PACKING	3		
30- 7	479-84526-00	BOLT	2		
30- 8	437-84525-60	WASHER, special	2		
30- 9	275-84527-60	DAMPER	2		
30-10	341-84751-61-35	BRACKET, licence	1		Silver
30-11	341-85111-60	REFLECTOR	2		
30-12	92903-05100	WASHER, spring	2		
30-13	95303-05600	NUT	2		
30-14	91203-06025	BOLT	1		
30-15	90209-06095	WASHER (102-28323-00)	1		
30-16	90387-07390	COLLAR	1		
30-17	90480-14102	DAMPER (214-21717-00)	1		
30-18	92901-06100	WASHER, spring	1		
30-19	95301-06600	NUT	1		
30-20	214-84553-01	DAMPER	1		
30-21	90109-06017	BOLT (168-21738-00)	2		
30-22	92901-08200	WASHER, plain	2		
30-23	92901-06100	WASHER, spring	2		
30-24	95301-06600	NUT	2		
30-25	214-84517-00	CORD, tail lamp	1		



Fig. 30 TAIL LAMP



YAMAHA TAIL LAMP

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
----------	-----------	-------------	------	---------------------------	---------


EXCLUSIVE PARTS FOR AUSTRALIA

30-0-2	341-84710-60	TAIL LAMP UNIT ASS'Y	1		
30-26	256-84714-61	BULB, tail lamp (12V-32/3cp)	1		
30-27	341-84721-60	LENS, tail lamp	1		

OPTIONAL PARTS

30-28	202-21681-00-33	PLATE, license rear	1		Yamaha Black
-------	-----------------	---------------------	---	--	--------------


Fig. 31 FLASHER LAMP



FLASHER LAMP

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
31- 1	254-83310-45-93	FRONT FLASHER LAMP ASS'Y	2		
	261-83310-95-93	FRONT FLASHER LAMP ASS'Y	2		Destined for Australia
31- 2	307-83330-20-93	REAR FLASHER LAMP ASS'Y	2		
	235-83330-95-93	REAR FLASHER LAMP ASS'Y	2		Destined for Australia
31- 3	183-83332-21	. LENS, flasher	4		
31- 4	183-83333-21	. SCREW, lens fitting	8		
31- 5	183-83313-70	. GASKET, flasher lens	4		
31- 6	136-83311-20	. BULB, flasher (12V-8W) ..	4		
31- 7	95301-08600	NUT, hexagon	4		
31- 8	92901-08100	WASHER, spring	4		


Fig. 32 ELECTRICAL



ELECTRICAL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
32- 1	118-82110-71	BATTERY ASS'Y	1	U.R	
	118-82110-80	BATTERY ASS'Y			
32- 2	170-82112-00	PIPE, breather (5-460)	1		
32- 3	118-82122-00	SEAT, battery	1		
32- 4	120-82131-00	BAND, battery	1		
32- 5	307-82115-01	WIRE, plus lead	1		
32- 6	396-82116-00	WIRE, minus lead	1		
32- 7	164-82150-00	FUSE HOLDER ASS'Y	1		
32- 8	148-82151-00	FUSE	2		
32- 9	357-81970-60	RECTIFIER ASS'Y	1		
32-10	95301-05600	NUT	1		
32-11	92901-05100	WASHER, spring	1		
32-12	396-82508-31	MAIN SWITCH ASS'Y	1		
32-13	98701-05015	SCREW, flathead	2		
32-14	254-82310-60	IGNITION COIL ASS'Y	2		
32-15	95301-06600	NUT	4		
32-16	92901-06100	WASHER, spring	4		
32-17	183-82341-00	CORD, hightension	2		
32-18	166-82370-20	PLUG CAP ASS'Y	2		
	808-82370-10	PLUG CAP ASS'Y	2		Alternate Parts
32-19	307-82530-00	STOP SWITCH ASS'Y (With Noise Suppressor)	1		
32-20	136-82540-00	NEUTRAL SWITCH ASS'Y	1		
32-21	90430-11034	GASKET (136-82543-00)	1		
32-22	337-83350-20	FLASHER RELAY ASS'Y	1		
32-23	92501-06012	SCREW, panhead	1		
32-24	92901-06100	WASHER, spring	1		
32-25	183-83371-21	HORN	1		
32-26	92501-06015	SCREW, panhead	1		
32-27	92501-06025	SCREW, panhead	1		

Fig. 32 ELECTRICAL



ELECTRICAL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
32-28	92901-06100	WASHER, spring	2		
32-29	396-82590-31	WIRE HARNESS ASS'Y .54	1		
32-30	307-82599-01	COVER, connector	1		

ALTERNATE PARTS

32-31	327-81911-10	RESISTOR	1		
32-32	97301-06010	BOLT, hexagon	2		
32-33	92901-06100	WASHER, spring	2		
32-34	389-81971-00	WIRE, read	1		
32-35	341-26397-01	BAND	1		

NUMERICAL INDEX



NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
26-26	102-25137-00	8-13	132-15664-00	5-26	164-17427-00-08
27-26	102-25412-00	8-11	132-15676-00	5- 9	164-17427-00-10
12-19	102-27114-00	2-10	132-16346-00	5-26	164-17427-00-10
26-23	109-25136-00	4- 9	132-16351-00	5- 9	164-17427-00-12
26- 9	109-25315-00	4- 2	132-16369-00	5-26	164-17427-00-12
14- 9	110-81345-20	4- 5	132-16371-02	6- 4	164-18551-00
8-15	117-15644-00	7-10	132-18113-01	6-11	164-18561-00
32- 1	118-82110-71	6-14	132-18140-01	17- 6	164-22216-00
32- 1	118-82110-80	18-18	132-27414-00	20- 6	164-23125-00
32- 3	118-82122-00	18-19	132-27417-00	20- 9	164-23145-01
1-24	120-15371-00	18-17	132-27422-00	20- 7	164-23147-00
17-19	120-27433-00	3-18	136-11561-00-03	20-13	164-23163-00
32- 4	120-82131-00	3-18	136-11561-00-04	21- 9	164-23441-00-98
3- 7	122-11681-00	3-18	136-11561-00-05	14- 4	164-81246-21
4-17	122-16164-00	3-18	136-11561-00-06	32- 7	164-82150-00
19-14	122-21582-81-33	3-18	136-11561-00-07	32-18	166-82370-20
20-22	122-23119-01	3-18	136-11561-00-08	23-19	168-24512-00
20-23	122-23129-00	21- 6	136-23415-00	23-14	168-24522-00
20-20	122-23346-01	32-20	136-82540-00	22-35	168-83936-01
21-25	122-23480-00	31- 6	136-83311-20	32- 2	170-82112-00
21-26	122-23483-00	13-17	137-13128-00	19-15	173-21581-80-93
23- 7	122-24181-00	13-11	137-13137-00-03	17- 5	173-22151-00
18- 2	122-27112-00	13-11	137-13137-00-05	13- 3	174-13175-00
29- 2	123-83516-20	13-11	137-13137-00-10	5-32	174-17461-30
29- 7	123-83516-20	13-11	137-13137-00-30	5-32	174-17461-40
13- 1	126-13116-00	13-11	137-13137-00-50	5-32	174-17461-50
5-24	131-15643-00	13-12	137-13138-01	5-32	174-17461-60
4- 4	131-16154-00	13- 5	137-13176-00	19- 4	174-21518-00-93
3- 2	132-11422-03	6-23	137-15353-00	21-18	174-23421-00
3- 3	132-11432-03	4-14	137-16356-00	21-20	174-23425-00
3-12	132-11511-02	23-18	137-24523-00	25-14	174-24741-00
3-17	132-11515-01	22-23	137-26243-60	8-16	180-15641-00
3- 9	132-11561-00-03	30- 3	137-84714-61	8-18	180-15660-00
13- 7	132-13178-01	32- 8	148-82151-00	8-17	180-15687-00
12- 4	132-14613-00	26-37	152-25163-00	1-20	183-11181-00
12-17	132-14713-00	8- 2	156-15618-01	3- 1	183-11412-02
12-18	132-14714-01	21- 1	156-23411-00	3-14	183-11512-00
5-11	132-15389-00	21- 2	156-23412-00	3-28	183-11633-00
4-16	132-15631-00	5- 9	164-17427-00-08	2- 2	183-15418-01

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
5-25	183-15651-00	14-11	183-81451-12	28- 1	237-84330-60-G6
4-15	183-16181-01	32-17	183-82341-00	28- 1	237-84330-60-M3
5- 8	183-17121-01	31- 5	183-83313-70	1-26	241-15357-00
5- 3	183-17151-00	31- 3	183-83332-21	2- 6	241-16341-01
5-21	183-17251-00	31- 4	183-83333-21	2- 8	241-16342-00
5- 2	183-17411-00	32-25	183-83371-21	21-13	246-23428-00
5-15	183-17421-00	28- 6	183-84314-60	9- 2	248-17831-01
6- 0-1	183-18500-02	28- 5	195-84324-00	9- 3	248-17837-00
6- 2	183-18511-00	28- 8	195-84325-00	9- 4	248-17841-00
6- 6	183-18512-00	30-28	202-21681-00-33	27-30	248-25388-00
6- 7	183-18513-00	22- 1	212-26111-00	2-20	252-15451-00
6- 1	183-18541-02	9- 6	214-17811-01	20-14	252-23116-00
17-14	183-22332-01	9-10	214-17812-00	20-26	252-23121-00-G6
20-16	183-23112-00	9-13	214-17843-00	20-26	252-23121-00-M3
20-19	183-23318-00	9- 8	214-17847-00	20- 5	252-23124-00
21- 4	183-23411-00	24- 3	214-21771-00	20-27	252-23131-00-G6
21- 3	183-23412-00	27-36	214-25388-00	20-27	252-23131-00-M3
21-19	183-23422-00	22- 0-1	214-82910-02	20-10	252-23144-00
26-32	183-25118-00	22- 4	214-82911-01	20- 4	252-23149-00
26-15	183-25149-00	29- 4	214-83513-00	29- 8	252-83520-01
27- 0-1	183-25304-00	29- 9	214-83513-00	29-15	252-83550-00
27- 1	183-25311-00	29-11	214-83523-00	28- 0-1	252-84310-00
27- 9	183-25315-00	22- 5	214-83912-00	28- 7	252-84312-00
27-15	183-25321-00	22-15	214-83913-00	32-14	254-82310-60
27-17	183-25330-01	22- 7	214-83913-00	31- 1	254-83310-45-93
26-20	183-25351-00	28- 2	214-84153-60	13- 2	256-17837-00
27-16	183-25351-00	30-25	214-84517-00	28- 0-2	256-84301-61
27-23	183-25366-01	30-20	214-84553-01	28-10	256-84347-00
27-22	183-25387-00	22-19	232-83980-30	28-11	256-84350-61
27- 2	183-25396-90	22- 0-2	233-82920-32	28- 9	256-84357-61
27- 3	183-25397-90	22-10	233-82921-31	30-26	256-84714-61
27-24	183-25437-10	22-11	233-83922-30	31- 1	261-83310-95-93
27-24	183-25438-10	22- 2	235-26241-10	30- 2	275-84523-60
27-24	183-25439-10	31- 2	235-83330-95-93	30- 9	275-84527-60
22- 1	183-26111-10	29- 3	235-83536-21	25-12	276-24748-00
14- 3	183-81421-10	9- 1	237-17861-00	13-25	278-13161-00
14- 7	183-81425-10	29-12	237-83523-00	8- 1	278-15611-00-93
14- 8	183-81431-10	28- 3	237-84315-00	25-11	278-24728-00
14-10	183-81432-10	28- 4	237-84320-00	11-30	288-14161-00

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
13-28	293-13174-00	17- 7	307-22210-00-G6	14- 1	307-81450-10
27-14	304-25364-00	17- 7	307-22210-00-M3	32- 5	307-82115-01
22-24	306-26242-10	17-12	307-22311-00-93	16-19	307-82121-00
30- 1	306-84711-60	20-17	307-23111-00	32-19	307-82530-00
3-15	307-11541-00	20-15	307-23114-00	32-30	307-82599-01
3-30	307-11601-01	20-11	307-23122-00-93	31- 2	307-83330-20-93
3-30	307-11601-11	20-12	307-23132-00-93	23- 4	322-24161-00
3-30	307-11601-21	20- 2	307-23136-00-35	7-15	326-18115-00
3-30	307-11601-31	20- 3	307-23141-00	22-36	326-26328-00
3-30	307-11601-41	20- 8	307-23150-01	32-31	327-81911-10
12- 3	307-14612-00	20-18	307-23340-00-33	4- 6	336-16324-00
12-10	307-14753-00	21-17	307-23419-00	8- 5	337-15621-01-91
2-27	307-15363-00	21- 8	307-23435-00-98	25-13	337-24768-00
4- 1	307-16150-00	23- 8	307-24182-00	32-22	337-83350-20
4- 0-1	307-16301-00	24- 5	307-24319-00	29-10	337-83519-00-33
4- 8	307-16321-00	25-15	307-24830-01	32-35	341-26397-01
4-19	307-16357-00	26- 0-1	307-25104-00	30- 0-1	341-84710-00
4- 7	307-16367-00	26- 1	307-25111-00	30- 4	341-84721-00
5- 7	307-17131-00	26-12	307-25121-00	30-27	341-84721-60
5- 6	307-17141-00	26-17	307-25130-00	30- 6	341-84722-60
5-22	307-17211-01	26-14	307-25135-00	30- 5	341-84724-60
5-16	307-17221-01	26-21	307-25138-00	30-10	341-84751-61-35
5-17	307-17231-00	26-27	307-25155-00	20-28	341-85111-00
5-18	307-17241-00	26-28	307-25156-00	30-11	341-85111-60
5- 1	307-17410-00	26-39	307-25161-00	13-21	353-13552-01
5-13	307-17471-00	26- 2	307-25196-90	25- 9	353-24705-04
7- 1	307-18101-01	26- 3	307-25197-90	32- 9	357-81970-60
7- 9	307-18111-00-93	27-19	307-25355-00	24- 2	360-21761-00
7-17	307-18112-00-93	27-41	307-25371-00	23-12	360-24500-00
2- 4	307-18188-00	22- 1	307-26111-20	23-17	360-24512-00
6-20	307-18533-00	22-20	307-26281-00	23-15	360-24515-00
6-18	307-18571-00	22-21	307-26282-00	23-13	360-24521-00
15- 9	307-21165-00-33	18- 1	307-27111-00	22-26	360-26261-01
15- 2	307-21315-00-33	18- 6	307-27115-00	11-32	367-14169-00
19-13	307-21510-80-93	18- 3	307-27211-10-93	11- 5	367-14195-00
19- 7	307-21610-00-93	18- 8	307-27231-00	11- 1	367-14342-22
17- 2	307-22123-00	18-22	307-27413-00	11- 6	367-14385-00
17- 3	307-22141-70	14- 0-1	307-81400-10	11- 7	367-14386-00
		14- 2	307-81410-10	30- 0-2	371-84710-60

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
26-34	382-25181-01	1-18	396-11311-04	22-28	396-26321-00
27-28	382-25381-01	1-19	396-11321-04	22-29	396-26335-10
22-40	382-26290-30	1-17	396-11351-00	22-29	396-26335-20
22-39	382-26290-40	11-31	396-14124-00	22-29	396-26335-40
3- 4	389-11442-00	11-26	396-14136-00	22-30	396-26341-10
10-20	389-13555-00	11-19	396-14211-00	22-30	396-26341-20
10-14	389-13610-01	11-23	396-14312-20	18-15	396-27411-01
10-15	389-13613-00	11-23	396-14313-20	18-16	396-27412-00
10-16	389-13616-01	11-21	396-14323-00	15-10	396-28100-11
10-19	389-13621-00	11-27	396-14331-00	32- 6	396-82116-00
10-21	389-13622-00	11-24	396-14336-00	32-12	396-82508-31
11-26	389-14126-00	11- 2	396-14341-00	32-29	396-82590-31
11-25	389-14137-00	11- 3	396-14343-46	29- 1	396-83510-20
11-15	389-14138-00	11-33	396-14348-00	29- 1	396-83510-40
11-12	389-14147-00	11-13	396-14371-00	29- 6	396-83540-00
11-29	389-14168-00-33	11-16	396-14374-00	29-16	396-83560-00
11-20	389-14212-00	11- 4	396-14390-16	22- 3	396-83972-10
11-18	389-14261-01	10- 2	396-14451-00	22- 3	396-83972-20
11-22	389-14333-00	12- 1	396-14611-00	11- 8	397-14181-00-33
11-14	389-14335-00	12- 2	396-14621-00	11- 8	397-14183-00-33
11-35	389-14349-00	12-13	396-14771-00	10- 1	397-14411-00
11-17	389-14373-00	12-14	396-14781-00	10- 4	397-14422-00
11- 9	389-14384-00	2- 1	396-15410-00	23- 2	397-24254-20
11-34	389-14396-00	2-14	396-15417-00	23- 2	397-24255-20
10- 3	389-14412-01	2-19	396-15421-00	23- 3	397-24256-20
10-10	389-14453-00	15- 1	396-21110-01-33	23- 3	397-24257-20
10-11	389-14463-00	16-12	396-21170-00-33	23- 1	398-24110-Y0-01
1- 1	389-15111-00	24- 1	396-21705-01-G6	23- 1	398-24110-Y0-02
1- 5	389-15118-00	24- 1	396-21705-01-M3	25- 1	398-24730-02
1- 2	389-15121-00	16- 1	396-21711-01-G6	25- 1-1	398-24731-00
1- 4	389-15128-00	16- 1	396-21711-01-M3	13-13	402-13146-00
2-16	389-15415-00	24-12	396-21781-01	22-40	407-26290-50
2-24	389-15416-00	16- 4	396-21782-01	22-39	407-26290-60
2-18	389-15425-00	17-23	396-22210-20	1-21	416-11111-00
2-25	389-15426-00	20- 0-1	396-23101-00	3- 0-1	416-11400-00
3-24	389-16111-00	20- 1	396-23126-00-35	3- 5	416-11651-00
25- 2	389-24726-00-33	22-25	396-26311-10	13- 0-1	416-13101-00
25- 4	389-24756-00	22-25	396-26311-20	16- 6	416-21717-00
32-34	389-81971-00	22-27	396-26312-00	23- 5	417-24602-00

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
30- 8	437-84525-60	18-24	90109-10399	17-10	90201-14218
17-18	465-27431-00	6-24	90109-14385	8- 7	90201-15234
3- 0-2	466-11630-00	4-21	90113-06013	5- 4	90201-20266
3- 0-2	466-11630-10	1-16	90116-06100	5-20	90201-20266
3- 0-2	466-11630-20	12- 5	90116-08166	26-13	90201-20269
3- 0-2	466-11630-30	20-24	90119-08010	17-20	90201-20279
3- 0-2	466-11630-40	22-31	90123-06010	5-23	90201-25290
3-27	466-11631-01-97	22-33	90123-08046	21-15	90202-06008
3-27	466-11631-01-98	14-12	90143-07022	3-25	90208-12015
3-27	466-11635-01	4-11	90149-05057	4-12	90208-12015
3-27	466-11636-01	17-13	90149-06012	29-13	90209-05029
3-27	466-11637-01	7- 4	90149-08094	30-15	90209-06095
3-27	466-11638-01	27-27	90170-08157	21-12	90209-17057
12- 8	466-14710-01	4-13	90170-12060	3- 8	90209-18112
12- 9	466-14720-01	17- 4	90170-12065	5-34	90215-16020
16- 7	466-21717-00	21-14	90170-16164	17-21	90240-06042
16- 8	466-21778-01	27-37	90170-20167	7-14	90240-08013
16-11	466-21783-20	18-25	90171-10012	6- 9	90249-04039
24-14	466-21783-20	26-36	90171-12005	26-40	90249-06095
19- 1	478-21510-01-93	27-38	90171-14006	18-13	90249-12008
30- 7	479-84526-00	1-22	90176-06002	6- 3	90250-10020
23- 6	498-24612-00	17- 8	90176-10013	2- 3	90266-06005
11- 0-1	507-14301-60	21-21	90179-06032	3-32	90280-03017
11- 0-2	507-14302-60	22-32	90179-06143	3-33	90282-05005
17- 1	507-22110-00-33	18-14	90179-06176	1-14	90340-12005
18-23	507-27311-00	22-34	90179-08148	9- 9	90383-10005
18-27	507-27315-01	3-26	90179-12044	30-16	90387-07390
15- 8	803-82591-00	5-33	90179-16018	26-31	90387-12095
32-18	808-82370-10	21- 7	90179-25033	26-33	90387-12099
27-39	90101-08034	16- 5	90183-03006	27-31	90387-15425
15- 7	90105-08026	24-13	90183-03006	3-23	90387-20163
17-11	90106-08027	21-16	90201-06061	27-35	90387-20165
22-14	90109-05197	26-22	90201-07076	5-31	90387-20346
6-15	90109-06001	17-15	90201-07079	13-24	90430-04004
30-21	90109-06017	7-16	90201-08085	1-29	90430-06011
27-25	90109-08057	17- 9	90201-10140	32-21	90430-11034
27-42	90109-08063	6-17	90201-12166	1-15	90430-12038
18-20	90109-08193	7-11	90201-12174	24- 4	90430-29114
27-46	90109-08368	7- 7	90201-12183	13-26	90445-05217

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
24-11	90445-08047	17-22	91401-16012	2-26	92506-06035
23-10	90445-09078	18-10	91401-20012	2-23	92506-06040
23-9	90445-09083	27-48	91401-20012	2-12	92506-06060
1-25	90446-06008	18-26	91401-20025	2-13	92506-06120
10-13	90460-37026	6-5	91401-25020	10-22	92706-06025
10-12	90460-49058	26-42	91401-30022	10-18	92901-03100
23-11	90467-08003	27-29	91401-30030	11-11	92901-04100
24-6	90467-08003	25-3	91501-05055	14-5	92901-04100
13-22	90468-02033	2-5	91609-30014	14-6	92901-04200
13-27	90468-02033	11-36	91690-20008	6-13	92901-05100
21-22	90468-10050	1-12	91810-02015	12-12	92901-05100
29-14	90468-10050	2-21	91810-02015	13-14	92901-05100
27-45	90468-12007	1-3	91810-09016	20-29	92901-05100
19-12	90480-12013	16-9	92501-06008	32-11	92901-05100
30-17	90480-14102	9-11	92501-06010	22-17	92901-05200
13-20	90501-02018	10-6	92501-06010	20-30	92901-05200
18-12	90501-10245	25-5	92501-06010	9-12	92901-06100
8-3	90501-12081	1-6	92501-06012	10-8	92901-06100
6-22	90501-12083	5-14	92501-06012	14-15	92901-06100
4-10	90501-20125	17-16	92501-06012	16-3	92901-06100
7-2	90506-09009	24-7	92501-06012	16-10	92901-06100
6-16	90506-09112	32-23	92501-06012	16-14	92901-06100
2-9	90506-10019	16-2	92501-06015	16-17	92901-06100
26-18	90506-16036	24-9	92501-06015	17-17	92901-06100
27-18	90506-16036	32-26	92501-06015	19-6	92901-06100
18-7	90506-29054	23-16	92501-06025	19-9	92901-06100
18-28	90507-29022	32-27	92501-06025	19-19	92901-06100
8-12	90508-26136	1-7	92501-06055	21-24	92901-06100
18-5	90508-32056	1-8	92501-06060	22-9	92901-06100
7-3	90508-32207	10-9	92501-06070	22-13	92901-06100
26-8	90560-12138	14-14	92501-06075	22-37	92901-06100
27-8	90560-15136	1-9	92501-06080	24-8	92901-06100
5-28	90560-20038	10-7	92501-06080	24-10	92901-06100
7-18	91101-06030	1-10	92501-06095	25-6	92901-06100
30-14	91203-06025	1-11	92501-06105	25-8	92901-06100
10-23	91316-08040	1-28	92503-06008	30-18	92901-06100
22-18	91401-12015	2-17	92506-06020	30-23	92901-06100
13-18	91401-12018	2-22	92506-06030	32-16	92901-06100
7-13	91401-16012	2-11	92506-06035		

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
32-24	92901-06100	2- 7	93104-11028	4-18	93501-04011
32-28	92901-06100	27-11	93104-22018	21- 5	93501-04011
32-33	92901-06100	26-19	93105-47007	6-21	93505-16006
1-23	92901-06200	27-34	93106-26005	13-19	93505-32002
10- 5	92901-06200	8- 9	93109-15001	8- 4	93507-32009
19-10	92901-06200	9- 7	93210-07100	1-13	93603-14026
16-15	92901-06600	9- 5	93210-13016	13- 4	93603-22028
18- 9	92901-06600	26-25	93210-14104	3-13	93604-18058
18-11	92901-06600	3-22	93210-18023	6- 8	93604-22050
25-10	92901-06600	27-13	93210-42101	26- 5	94125-18019
25-16	92901-06600	3-16	93210-48045	27- 4	94127-18064
12- 6	92901-08100	27-32	93306-00406	26- 6	94225-18006
12-16	92901-08100	27-12	93306-20204	27- 5	94227-18009
12-20	92901-08100	27-10	93306-20205	26- 7	94327-18008
14-13	92901-08100	3-10	93306-20526	27- 7	94327-18008
15- 5	92901-08100	26-10	93306-30103	26- 4	94414-18095
18-30	92901-08100	5-12	93306-30304	27- 6	94416-18018
19- 3	92901-08100	5-29	93306-30401	27-49	94504-28110
20-25	92901-08100	3-19	93306-30405	27-50	94604-28001
21-11	92901-08100	3-31	93310-11296	1-27	94701-00045
27-44	92901-08100	3- 6	93310-41809	13-15	95301-05600
29-18	92901-08100	5-10	93315-31502	32-10	95301-05600
31- 8	92901-08100	4- 3	93341-22302	22-16	95301-05900
30-22	92901-08200	5-27	93410-15005	27-21	95301-06600
13- 8	92901-08400	8-10	93410-15005	16-18	95301-06600
20-21	92901-10100	26-16	93410-20009	19- 5	95301-06600
18-21	92901-10600	8-14	93410-25017	22-38	95301-06600
26-35	92901-12100	27-33	93420-42007	26-30	95301-06600
30-12	92903-05100	6-10	93430-03014	30-19	95301-06600
19-18	92903-06600	26-41	93430-04003	30-24	95301-06600
10-24	92906-08100	7- 8	93430-10016	32-15	95301-06600
10-25	92906-08200	7-12	93430-10016	4-20	95301-06700
13-16	93101-10001	8- 8	93430-10016	22- 8	95301-06700
13- 6	93101-10002	18- 4	93430-12008	26-38	95301-06700
7- 6	93101-12004	6-19	93440-15012	7- 5	95301-08600
26-11	93102-18008	5- 5	93440-20043	12- 7	95301-08600
3-20	93102-20117	5-19	93440-20043	12-15	95301-08600
5-30	93102-28021	3-29	93450-13022	12-21	95301-08600
3-21	93103-28011	3-11	93450-52010	27-47	95301-08600
26-24	93104-07003				

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
31- 7	95301-08600				
13- 9	95301-08700				
27-40	95301-08700				
27-43	95301-08700				
30-13	95303-05600				
19-17	95303-06600				
15- 4	95701-08100				
15- 3	95821-08055				
15- 6	95821-08110				
21-23	97301-06010				
32-32	97301-06010				
19-11	97301-06012				
25- 7	97301-06012				
27-20	97301-06025				
26-29	97301-06030				
16-16	97301-06045				
19- 8	97301-06050				
16-13	97301-06070				
19- 2	97301-08010				
29-17	97301-08015				
18-29	97301-08020				
19-16	97303-06012				
22- 6	97303-06020				
22-12	97303-06020				
21-10	97303-08035				
8- 6	97311-06025				
11-10	98501-04010				
12-11	98501-05010				
6-12	98501-05012				
13-10	98501-05015				
22-22	98501-05015				
2-15	98506-05012				
10-17	98512-03008				
32-13	98701-09015				
13-23	98901-04008				

YAMAHA RD125B PARTS LIST



YAMAHA MOTOR CO., LTD.

PRINTED IN JAPAN
First edition Dec., 1974
(466-28198-05)